

WRB - joints lapped and taped  
(DuPont™ Tyvek® Tape)

Mesh screen at top  
of wall over cross-  
vented batten

Mesh screen at  
window head

WRB (DuPont™ Tyvek®  
HomeWrap®, Grade D building  
paper, building felt)

Metal lathe

Stucco scratch coat

Stucco final coat

Window installed per best  
practice sequence - after WRB

Jamb extension- provide 1" gap  
between foam and window

DuPont™ RainVent™  
Batten placed over WRB

DuPont™ Tyvek®  
HomeWrap® or DuPont™  
Tyvek® StuccoWrap®

DuPont™ Tyvek® WrapCaps

Exterior continuous insulation

DuPont™ Flashing Tape  
seals joint at base of wall

Mesh screen at wall base  
over cross-vented batten  
(allows air flow through)

WRB over-lapped over  
base flashing  
(skip taped or fully taped)

